


➤ Références



## Commande frontale

Calibre (A)	Nb pôles	Appareil nu Cde directe	Appareil nu Cde extérieure	Poignée directe	Poignée extérieure	Axe pour poignée extérieure	Contact auxiliaire				
ND 125 A	3 P	2915 3012	2921 3012	Noire 3629 7901 <sup>(1)</sup>	Type S2 Noire IP55 1421 2111 <sup>(1)</sup> Noire IP65 1423 2111 Rouge IP65 1424 2111	200 mm 1400 1020 320 mm 1400 1032 <sup>(1)</sup> 500 mm 1400 1050	1 <sup>er</sup> contact OF 3999 0021 <sup>(2)(3)</sup> 2 contacts OF 3999 0022 <sup>(2)(3)</sup> 1 contact F 3999 0701 <sup>(2)(4)</sup> 1 contact O 3999 0702 <sup>(2)(4)</sup>				
	4 P	2915 4012	2921 4012								
ND 200 A	3 P	2915 3021	2921 3020								
	4 P	2915 4021	2921 4020								
ND 250 A	3 P	2915 3025	2921 3025								
	4 P	2915 4025	2921 4025								
ND 315 A	3 P	2915 3031	2921 3031								
	4 P	2915 4031	2921 4031								
ND 400 A	3 P	2915 3041	2921 3041								
	4 P	2915 4041	2921 4041								
ND 500 A	3 P	2915 3051	2921 3051								
	4 P	2915 4051	2921 4051								
630 A	3 P	2900 3063	2900 3063					Noire 2799 7012 <sup>(1)</sup> Rouge 2799 7013	Type S4 Noire IP65 1443 3111 <sup>(1)</sup> Rouge/Jaune IP65 1444 3111	200 mm 1401 1520 320 mm 1401 1532 <sup>(1)</sup> 400 mm 1401 1540	1 <sup>er</sup> inverseur OF 2799 0001 <sup>(2)</sup> 2 <sup>e</sup> contact OF 2799 0002 <sup>(2)</sup>
	4 P	2900 4063	2900 4063								
800 A	3 P	2900 3080	2900 3080								
	4 P	2900 4080	2900 4080								
1 250 A	3 P	2900 3120	2900 3120								
	4 P	2900 4120	2900 4120								
1 600 A	3 P	2900 3160	2900 3160								
	4 P	2900 4160	2900 4160								

(1) Standard.

(2) Contact auxiliaire de signalisation - Type S.

(3) Pour commande directe.

(4) Pour commande extérieure.